



Four Wheel Drive

60 - 85 - 110 L Hanging Water Bladder

Installation Guide

17 Pickett St

Dandenong,

Victoria

3175



Introduction

Thank you for purchasing one of our 4WD water bladders, we hope that our product serves you for many years, in your exploration of the great outdoors. We have designed your water bladder with three key points in mind:

1. Easy water storage solution when travelling.
2. A compactable unit that, once emptied, can be rolled up and stored in a fraction of the space required by other solutions.
- Durability - if you look after it and follow the suggestions below the bladder will work time and time again.

Component List:

- | | |
|--|---|
| 1. 4 x 13mm Hose Clips (Black) | 6. 1 x 25mm inlet hose kit with screw-cap end |
| 2. 2 x 25mm Hose Clips (Black) | 7. 1 x 25mm threaded inlet cap (Black) |
| 3. 1 x 13mm Outlet Hose with Tap | 8. 3 x mounting cable/zip ties (Black) |
| 4. 1 x 13mm Breather Hose with screw-cap end | 9. 1 x Roll of white Teflon Tape |
| 5. 1 x 13mm Threaded Breather Cap | 10. 1 x hanging style water Bladder |

Installation guide:

1. Make sure there are no sharp or protruding objects that may come into contact with the bladder in the area of installation.
2. If you are installing the bladder in the back of a ute or tray, consider lining the bottom of the installation area with outdoor or marine carpet and / or low friction material (not rubber).
3. Before using your water bladder, please wash out with fresh, filtered, cold water, as this will remove any trace of materials used in the production of this bladder.
4. Remember to wash out and air-dry the bladder after every trip, as this will extend the life of the bladder and prevent any tainting from occurring.
5. When storing, please store out of direct sunlight and extremes in heat and cold.
6. Remember, when cleaning the bladder, to not use hot water, or any solvents of any type, or any abrasive materials.
7. When filling, ensure that the Breather Hose is open and outside the vehicle, in order to prevent over pressurization and long term seam failure.
8. In twin cab utes attach the bladder to seat catches located on the rear wall of the vehicle and ensure that the seat can be placed back in its standard locked position. If attaching to a cargo barrier, or rear tray, ensure that the base of the bladder is resting on the floor of the vehicle / tray.
9. As everybody's palate is different, we recommend the use of In-Line filters, in order to remove any potential water impurities and odors.
10. Note: Use of chlorinated drinking water may affect the taste of the water. We recommend non-chlorinated water for best results.
11. The Outlet can be used as an Inlet (in conjunction with a standard 13mm hose), using the 1" fitting as a Breather, if required. Caution: This method requires monitoring, to prevent any flooding of the vehicle.

Warranty Information:

- *This Warranty is valid for defects, or failures, of fitting, material defects or other production defects.
- *This Warranty does not cover damage to any other items that have been damaged due to "Fleximake" product failure.
- *This Warranty does not cover any other failures stipulated outside the terms of this Warranty.
- *This Warranty is valid for two (2) years from the time of purchase from Fleximake and not from any second party.